



Correct Towing Positions for Torsion Axles

Correct Level




Trailer is level, note position of the tires

Hitch Too High



Trailer is not level, note that most of the load is on the rear axle

Hitch Too Low



Trailer is not level, note that most of the load is on the front axle